

Assembly Instructions for: 31600 Motor Carrier

TOOLS Required:

Hammer


Page 1

<u>CAUTION:</u> Tubing will crush if over-tightened.

Step 1: Motor Carrier Assembly

<u>A.</u> Slide bottom braces on axle using large holes as shown.

<u>**B.</u>** Slide Upright support tube on axle using large holes as shown.</u>



Step 2:

- A. Place plastic washer on axle.
- **<u>B.</u>** Place wheel on axle as shown.

<u>C.</u> Secure with pin. **Bend pin to secure in place** <u>D.</u> Place caps on wheels. Gently tap into place with hammer.



DEARCELIEX / EE3-9n PO Box 8, 644 2nd Street St. Paul Park, MN 55071

<u>Step 3</u>:

Place tank tie straps on upright supports as shown.



Step 4:

Attach plastic block to each end of upright support by aligning holes. Insert 4 bolts (2 7/8" long) and tighten fasteners.

NOTE: Top of block should be even with ends of upright tubes as shown.





Assembly Instructions for: 31600 Motor Carrier


Page 2

Step 5: Handle Assembly

Insert handles into short bottom U tube. Align holes in assembly so that the handles will point AWAY from each other and insert bolts.

NOTE: DO NOT add fasteners yet.






<u>NOTE</u>: Rigidity of cart is obtained through the following assemblies; some force will be needed to align certain holes.

Step 6:

Slide handles assembly into upright support assembly. Insert bolts in bottom brace and finger tighten fasteners.

NOTE: Handles will rest on outsides of upright support tubes. Make sure plastic block is facing up as shown.



<u>Step 7</u>:

Align holes to fasten handles to upright support. (May need to turn assembly "up-side-down") Insert bolt and finger tighten fasteners.





PO Box 8, 644 2nd Street St. Paul Park, MN 55071 Phone: (651) 459-9795 E-mail: <u>mail@gareick.com</u> On the Web: <u>www.garelick.com</u> Revision Date: 08/07




Assembly Instructions for: 31600 Motor Carrier

Page 3

<u>Step 8</u>:


Attach handle brace (tube with rounded ends) across top. Insert bolts and finger tighten fasteners.

Drape tank tie straps over wood block so loops are above holes.



<u>Step 9</u>:

Position tank holder U tube as shown. NOTE: Place tank holder on inside of main upright tube. U opens out facing forward. Insert bolts and finger tighten fasteners.



Step 10: Tighten all fasteners on carrier.

DERELICIX / **EE:9n** PO Box 8, 644 2nd Street St. Paul Park, MN 55071

Finished Assembly:



Maintenance:

Periodically lubricate wheels and polish** aluminum to ensure a long life.

NOTE: Recommended for motors 1-30 h.p./130 lbs.

**EEz-In marine polish, Model 65010, available.