

Marina power and RV park equipment

# Parts handbook

Volume VII



**EATON**

*Powering Business Worldwide*




# CONTENTS



Power ..... 3



Connections ..... 13



Lighting ..... 17



Water ..... 19



Housing ..... 21



Warranty policy ..... 24



Maintenance and cleaning ..... 25



### **Complete, high-quality electrical distribution equipment for marina and RV park applications**

Known as a leader in power pedestals and electrical distribution products and services, Eaton is a quality-driven company that constantly looks for ways to provide enhanced products and service solutions for their customers. Eaton can provide marina and RV park developers a complete electrical solution. For more information on our products, visit us online at [www.marinapower.com](http://www.marinapower.com).

#### **Eaton offers:**

- Complimentary comprehensive in-house electrical designs for your complete development using all high-quality Eaton products
- Complete remote wireless digital electronic meter reading for your development
- High-quality power pedestals and distribution equipment
- Electrical needs for your surrounding development—lighting, safety switches, loadcenters, wiring and more

#### **How to buy online**



Scan the QR code for more information.

#### **Marina Power and Lighting**
















Please contact our sales staff today to learn more about our high-quality marina power equipment. All transactions through Eaton's Order Center are covered under Eaton's Selling Policy 25-000.

Toll Free: (800) 723-8009









Phone: (757) 258-8800









Email: [marinasales@eaton.com](mailto:marinasales@eaton.com)

# Power

















Description	Catalog number	Description	Catalog number
 <p>Complete single-phase copper bus bar assembly Lighthouse / Powerhouse Lighthouse SS / Powerhouse SS Admiral</p>	<b>MPL1140A</b>	 <p>Copper bus bar with nuts and washers 2 x 1 x 1/4 inches Lighthouse / Powerhouse Lighthouse SS / Powerhouse SS Admiral</p>	<b>MPL3471</b>
 <p>Complete 3F copper bus bar assembly Lighthouse / Powerhouse Lighthouse SS / Powerhouse SS Admiral</p>	<b>MPL1140FA</b>	 <p>Copper bus bar with nuts and washers 1 1/4 x 7/10 x 3/16 inches Newport Harbor Mate / Newport Camp Mate Hatteras Light</p>	<b>MPLNP3468</b>
 <p>Complete single-phase copper bus bar assembly Newport Harbor Mate / Newport Camp Mate Hatteras Light</p>	<b>MPLNP1108A</b>	 <p>Double-barrel terminal block (Firehouse bus bar) Firehouse</p>	<b>MPL3751</b>
 <p>Complete 3F copper bus bar assembly Newport Harbor Mate / Newport Camp Mate Hatteras Light</p>	<b>MPL1108FA</b>	 <p>Mechanical lug bus bar up to 300 MCM Lighthouse / Powerhouse Lighthouse SS / Powerhouse SS Admiral</p>	<b>MPL300MCM</b>
 <p>Complete single-phase aluminum mechanical bus bar assembly Newport Harbor Mate / Newport Camp Mate Hatteras Light</p>	<b>MPL1108MA</b>	 <p>Mechanical lug bus bar up to 350 MCM Lighthouse / Powerhouse Lighthouse SS / Powerhouse SS Admiral</p>	<b>MPL350MCM</b>
 <p>Complete 3F aluminum mechanical bus bar assembly Newport Harbor Mate / Newport Camp Mate Hatteras Light</p>	<b>MPL1108MFA</b>	 <p>Bus bar holder Newport Harbor Mate / Newport Camp Mate Hatteras Light</p>	<b>MPL1000</b>
 <p>Complete single-phase aluminum mechanical bus bar assembly 350 MCM Lighthouse / Powerhouse Lighthouse SS / Powerhouse SS Admiral</p>	<b>MPL1140MA</b>	 <p>Bus bar holder Lighthouse / Powerhouse Lighthouse SS / Powerhouse SS Admiral</p>	<b>MPL1100</b>
 <p>Complete 3F aluminum mechanical bus bar assembly 350 MCM Lighthouse / Powerhouse Lighthouse SS / Powerhouse SS Admiral</p>	<b>MPL1140MFA</b>		

## Power (continued)

Description	Catalog number
<b>Meter kits</b>	
 120 V single-element meter kit, 1 side, black counter	<b>MPL18EZ0</b>
 120 V single-element meter kit, 1 side, clear counter	<b>MPL18EZ0C</b>
 120 V single-element meter kit, 2 side, black counter	<b>MPL18EZ00</b>
 120 V single-element meter kit, 2 side, clear counter	<b>MPL18EZ00C</b>
120/240 V dual-element meter kit, 1 side, black counter	<b>MPL18EZ1</b>
120/240 V dual-element meter kit, 1 side, clear counter	<b>MPL18EZ1C</b>
120/240 V dual-element meter kit, 2 side, black counter	<b>MPL18EZ2</b>
120/240 V dual-element meter kit, 2 side, clear counter	<b>MPL18EZ2C</b>
120/208 V three-element meter kit, 1 side, black counter	<b>MPL18EZ3</b>
120/208 V three-element meter kit, 1 side, clear counter	<b>MPL18EZ3C</b>
480 V three-element meter kit, 1 side, black counter	<b>MPL18EZ4</b>
480 V three-element meter kit, 1 side, clear counter	<b>MPL18EZ4C</b>
277/480 V three-element meter kit, 1 side, black counter	<b>MPL18EZ5</b>
277/480 V three-element meter kit, 1 side, clear counter	<b>MPL18EZ5C</b>
Power wire extensions (for new installations)	<b>MPL18EZP1</b>
<b>Meter kits (quick-connect style wiring)</b>	
 120 V single-element meter kit, 1 side, black counter	<b>MPL18EZ0-R</b>
 120 V single-element meter kit, 1 side, clear counter	<b>MPL18EZ0C-R</b>
 120 V single-element meter kit, 2 side, black counter	<b>MPL18EZ00-R</b>
 120 V single-element meter kit, 2 side, clear counter	<b>MPL18EZ00C-R</b>
120/240 V dual-element meter kit, 1 side, black counter	<b>MPL18EZ1-R</b>
120/240 V dual-element meter kit, 1 side, clear counter	<b>MPL18EZ1C-R</b>
120/240 V dual-element meter kit, 2 side, black counter	<b>MPL18EZ2-R</b>
120/240 V dual-element meter kit, 2 side, clear counter	<b>MPL18EZ2C-R</b>
120/208 V three-element meter kit, 1 side, black counter	<b>MPL18EZ3-R</b>
120/208 V three-element meter kit, 1 side, clear counter	<b>MPL18EZ3C-R</b>
480 V three-element meter, 1 side, black counter	<b>MPL18EZ4-R</b>
480 V three-element meter, 1 side, clear counter	<b>MPL18EZ4C-R</b>
277/480 V three-element meter kit, 1 side, black counter	<b>MPL18EZ5-R</b>
277/480 V three-element meter kit, 1 side, clear counter	<b>MPL18EZ5C-R</b>












Description	Catalog number
 Counter (screw in/black) Newport Harbor Mate / Newport Camp Mate Hatteras Light Lighthouse / Powerhouse Lighthouse SS / Powerhouse SS Admiral MegaYacht	<b>MPL3021</b>
 Counter (snap in/clear) Newport Harbor Mate / Newport Camp Mate Hatteras Light Lighthouse / Powerhouse Lighthouse SS / Powerhouse SS Admiral MegaYacht	<b>MPL3021C</b>
 Lighthouse / Lighthouse SS 20 A GFCI-00 amber faceplate	<b>MPL1120</b>
 Lighthouse / Lighthouse SS 30 A-00 amber faceplate	<b>MPL1129</b>
 Lighthouse / Lighthouse 30 A-20 A GFCI amber faceplate	<b>MPL1121</b>
 Lighthouse / Lighthouse SS 30 A-50 A amber faceplate	<b>MPL1122</b>
 Lighthouse / Lighthouse SS 30 A-30 A amber faceplate	<b>MPL1127</b>
 Lighthouse / Lighthouse SS 50 A-50 A amber faceplate	<b>MPL1123</b>

## Power (continued)

Description	Catalog number	Description	Catalog number
Lighthouse / Lighthouse SS 50 A-20 A GFCI amber faceplate	<b>MPL1124</b>	Lighthouse / Lighthouse SS breaker plate	<b>MPL1141</b>
			
Lighthouse / Lighthouse SS 20 A GFCI-20 A GFCI amber faceplate	<b>MPL1125</b>	Powerhouse / Powerhouse SS breaker plate	<b>RV1112</b>
			
Lighthouse / Lighthouse SS 00-00 amber faceplate	<b>MPL1126</b>	Powerhouse / Powerhouse SS 50 A-20 A GFI receptacle plate	<b>RV114335</b>
			
Lighthouse / Lighthouse SS 50 A-00 amber faceplate	<b>MPL1128</b>	Powerhouse / Powerhouse SS 30 A-00 and 50 A-00 receptacle plate	<b>RV11433</b>
			
Universal faceplate—blank cover	<b>MPLFP00</b>	Newport Harbor Mate 30 A-30 A faceplate	<b>MPL1135</b>
			
Universal faceplate—20 A	<b>MPLFP20</b>	Newport Harbor Mate 30 A-50 A faceplate	<b>MPL1136</b>
			
Universal faceplate—30 A	<b>MPLFP30</b>	Newport Harbor Mate 50 A-50 A faceplate	<b>MPL1137</b>
			
Universal faceplate—50 A	<b>MPLFP50</b>	Newport Harbor Mate 50 A-00 faceplate	<b>MPL1138</b>
			

## Power (continued)



Description	Catalog number
 Newport Harbor Mate 30 A-00 faceplate	<b>MPL1139</b>
 Newport Harbor Mate 30 A-20 A faceplate	<b>MPL11392</b>
 Newport Harbor Mate 30 A-30 A-20 A faceplate	<b>MPL1150</b>
 Newport Harbor Mate 50 A-20 A faceplate	<b>MPL11382</b>
 Newport Harbor Mate 30 A-50 A-20 A faceplate	<b>MPL1151</b>
 Newport Camp Mate 30 A-30 A-20 A GFI faceplate	<b>RVPH1135</b>
 Newport Camp Mate 30 A-50 A-20 A GFI faceplate	<b>RVPH1136</b>
 Newport Camp Mate 50 A-50 A-20 A GFI faceplate	<b>RVPH1137</b>

Description	Catalog number
 Newport Camp Mate 50 A-20 A GFI faceplate	<b>RVPH1138</b>
 Newport Camp Mate 30 A-20 A GFI faceplate	<b>RVPH1139</b>
<b>Lighthouse faceplate assemblies</b>	
 Lighthouse / Lighthouse SS 20 A GFCI-00 amber faceplate assembly with breakers	<b>MPL1120A</b>
 Lighthouse / Lighthouse SS 30 A-00 amber faceplate assembly with breakers	<b>MPL1129A</b>
 Lighthouse / Lighthouse SS 30 A-00 amber faceplate assembly with GFCI breakers	<b>MPL1129A-GF</b>
 Lighthouse / Lighthouse SS 30 A-20 A GFCI amber faceplate assembly with breakers	<b>MPL1121A</b>
 Lighthouse / Lighthouse SS 30 A-20 A GFCI amber faceplate assembly with GFCI breakers	<b>MPL1121A-GF</b>
 Lighthouse / Lighthouse SS 30 A-50 A amber faceplate assembly with breakers	<b>MPL1122A</b>
 Lighthouse / Lighthouse SS 30 A-50 A amber faceplate assembly with GFCI breakers	<b>MPL1122A-GF</b>
 Lighthouse / Lighthouse SS 30 A-30 A amber faceplate assembly with breakers	<b>MPL1127A</b>
 Lighthouse / Lighthouse SS 30 A-30 A amber faceplate assembly with GFCI breakers	<b>MPL1127A-GF</b>































# Power (continued)

Description	Catalog number
<b>Lighthouse faceplate assemblies</b>	
 Lighthouse / Lighthouse SS 50 A-50 A amber faceplate assembly with breakers	<b>MPL1123A</b>
 Lighthouse / Lighthouse SS 50 A-20 A GFCI amber faceplate assembly with breakers	<b>MPL1124A</b>
Lighthouse / Lighthouse SS 50 A-20 A GFCI amber faceplate assembly with GFCI breakers	<b>MPL1124A-GF</b>
 Lighthouse / Lighthouse SS 20A GFCI-20 A GFCI amber faceplate assembly with breakers	<b>MPL1125A</b>
 Lighthouse / Lighthouse SS 50 A-00 amber faceplate assembly with breakers	<b>MPL1128A</b>
Lighthouse / Lighthouse SS 50 A-00 amber faceplate assembly with GFCI breakers	<b>MPL1128A-GF</b>
 Lighthouse SS 100 A 1F faceplate assembly with breakers and plate	<b>MPL1142XA</b>
 Lighthouse / Lighthouse SS 100 A 3F faceplate assembly with breakers and plate (120/208 V)	<b>MPL1142YA</b>
 Lighthouse / Lighthouse SS 100 A 3F faceplate assembly with breakers and plate (480 V)	<b>MPL1142YA4</b>
Lighthouse / Lighthouse SS 100 A 3F faceplate assembly with breakers and plate (277/480 V)	<b>MPL1142YA24</b>
 20 GFI flipcover assembly with breaker Lighthouse / Powerhouse Lighthouse SS / Powerhouse SS Admiral MegaYacht	<b>MPL1131</b>





























Description	Catalog number
<b>Lighthouse faceplate assemblies</b>	
 Hatteras Light 30 A faceplate assemblies	<b>MPL1131-2</b>
Hatteras Light 50 A 250 V faceplate assemblies	<b>MPL1131-4</b>
<b>Powerhouse faceplate assemblies</b>	
 Powerhouse / Powerhouse SS 30 A-20 A GFCI faceplate assembly with breakers	<b>RVPH1121A</b>
 Powerhouse / Powerhouse SS 50 A-20 A GFCI faceplate assembly with breakers	<b>RVPH1124A</b>
 Powerhouse / Powerhouse SS 30 A-50 A-20 A GFCI faceplate assembly with breakers	<b>RVPH1122A</b>
 Powerhouse / Powerhouse SS 30 A-30 A-20 A GFCI faceplate assembly with breakers	<b>RVPH1123A</b>
 Powerhouse / Powerhouse SS 50 A-50 A-20 A GFCI faceplate assembly with breakers	<b>RVPH1125A</b>
<b>Newport Harbor Mate faceplate assemblies (for units with stand)</b>	
 Newport Harbor Mate 30 A-30 A faceplate assembly with breakers (for units with stand)	<b>MPL1135A-2</b>
Newport Harbor Mate 30 A-30 A faceplate assembly with GFCI breakers (for units with stand)	<b>MPL1135A-2-GF</b>

## Power (continued)













Description	Catalog number
<b>Newport Harbor Mate faceplate assemblies (for units with stand)</b>	
 Newport Harbor Mate 30 A-50 A faceplate assembly with breakers (for units with stand)	<b>MPL1136A-2</b>
 Newport Harbor Mate 30 A-50 A faceplate assembly with GFCI breakers (for units with stand)	<b>MPL1136A-2-GF</b>
 Newport Harbor Mate 50 A-50 A faceplate assembly with breakers (for units with stand)	<b>MPL1137A-2</b>
 Newport Harbor Mate 50 A-50 A faceplate assembly with GFCI breakers (for units with stand)	<b>MPL1137A-2-GF</b>
 Newport Harbor Mate 50 A-00 faceplate assembly with breakers (for units with stand)	<b>MPL1138A-2</b>
 Newport Harbor Mate 50 A-00 faceplate assembly with GFCI breakers (for units with stand)	<b>MPL1138A-2-GF</b>
 Newport Harbor Mate 30 A-00 faceplate assembly with breakers (for units with stand)	<b>MPL1139A-2</b>
 Newport Harbor Mate 30 A-00 faceplate assembly with GFCI breakers (for units with stand)	<b>MPL1139A-2-GF</b>
 Newport Harbor Mate 30 A-30 A-20 A GFI faceplate assembly with breakers (for units with stand)	<b>MPL1150A-2</b>
 Newport Harbor Mate 30 A-30 A-20 A GFI faceplate assembly with GFCI breakers (for units with stand)	<b>MPL1150A-2-GF</b>
 Newport Harbor Mate 30 A-50 A-20 A GFI faceplate assembly with breakers (for units with stand)	<b>MPL1151A-2</b>
 Newport Harbor Mate 30 A-50 A-20 A GFI faceplate assembly with GFCI breakers (for units with stand)	<b>MPL1151A-2-GF</b>
 Newport Harbor Mate 50 A-50 A-20 A GFI faceplate assembly with breakers (for units with stand)	<b>MPL1152A-2</b>
 Newport Harbor Mate 50 A-50 A-20 A GFI faceplate assembly with GFCI breakers (for units with stand)	<b>MPL1152A-2-GF</b>

Description	Catalog number
<b>Newport Harbor Mate faceplate assemblies (for units with stand)</b>	
 Newport Harbor Mate 50 A-20 A GFI faceplate assembly with breakers (for units with stand)	<b>MPL1153A-2</b>
 Newport Harbor Mate 50 A-20 A GFI faceplate assembly with GFCI breakers (for units with stand)	<b>MPL1153A-2-GF</b>
 Newport Harbor Mate 30 A-20 A GFI faceplate assembly with breakers (for units with stand)	<b>MPL1154A-2</b>
 Newport Harbor Mate 30 A-20 A GFI faceplate assembly with GFCI breakers (for units with stand)	<b>MPL1154A-2-GF</b>
 Newport Harbor Mate 50 A-20 A GFI-20 A GFI faceplate assembly with breakers (for units with stand)	<b>MPL1155A-2</b>
 Newport Harbor Mate 50 A-20 A GFI-20 A GFI faceplate assembly with GFCI breakers (for units with stand)	<b>MPL1155A-2-GF</b>
 Newport Harbor Mate 30 A-20 A GFI-20 A GFI faceplate assembly with breakers (for units with stand)	<b>MPL1156A-2</b>
 Newport Harbor Mate 30 A-20 A GFI-20 A GFI faceplate assembly with GFCI breakers (for units with stand)	<b>MPL1156A-GF</b>
<b>Newport Harbor Mate faceplate assemblies</b>	
 Newport Harbor Mate 30 A-30 A faceplate assembly with breakers (for standless units)	<b>MPL1135A</b>
 Newport Harbor Mate 30 A-30 A faceplate assembly with GFCI breakers (for standless units)	<b>MPL1135A-GF</b>
 Newport Harbor Mate 30 A-50 A faceplate assembly with breakers (for standless units)	<b>MPL1136A</b>
 Newport Harbor Mate 30 A-50 A faceplate assembly with GFCI breakers (for standless units)	<b>MPL1136A-GF</b>
 Newport Harbor Mate 50 A-50 A faceplate assembly with breakers (for standless units)	<b>MPL1137A</b>
 Newport Harbor Mate 50 A-50 A faceplate assembly with GFCI breakers (for standless units)	<b>MPL1137A-GF</b>












## Power (continued)

Description	Catalog number	Description	Catalog number
<b>Newport Harbor Mate faceplate assemblies</b>		<b>Newport Harbor Mate faceplate assemblies</b>	
 <p>Newport Harbor Mate 50 A-00 faceplate assembly with breakers (for standless units)</p>	<b>MPL1138A</b>	 <p>Newport Harbor Mate 50 A-20 A GFI-20 A GFI faceplate assembly with breakers (for standless units)</p>	<b>MPL1155A</b>
 <p>Newport Harbor Mate 50 A-00 faceplate assembly with GFCI breakers (for standless units)</p>	<b>MPL1138A-GF</b>	 <p>Newport Harbor Mate 50 A-20 A GFI-20 A GFI faceplate assembly with GFCI breakers (for standless units)</p>	<b>MPL1155A-GF</b>
 <p>Newport Harbor Mate 30 A-00 faceplate assembly with breakers (for standless units)</p>	<b>MPL1139A</b>	 <p>Newport Harbor Mate 30 A-20 A GFI-20 A GFI faceplate assembly with breakers (for standless units)</p>	<b>MPL1156A</b>
 <p>Newport Harbor Mate 30 A-00 faceplate assembly with GFCI breakers (for standless units)</p>	<b>MPL1139A-GF</b>	 <p>Newport Harbor Mate 30 A-20 A GFI-20 A GFI faceplate assembly with GFCI breakers (for standless units)</p>	<b>MPL1156A-GF</b>
 <p>Newport Harbor Mate 30 A-30 A-20 A GFI faceplate assembly with breakers (for standless units)</p>	<b>MPL1150A</b>	 <p>Newport Camp Mate 30 A-30 A-20 A GFI faceplate assembly with breakers (for standless units)</p>	<b>RV1150A</b>
 <p>Newport Harbor Mate 30 A-30 A-20 A GFI faceplate assembly with GFCI breakers (for standless units)</p>	<b>MPL1150A-GF</b>	 <p>Newport Camp Mate 30 A-30 A-20 A GFI faceplate assembly with breakers (for standless units)</p>	<b>RV1151A</b>
 <p>Newport Harbor Mate 30 A-50 A-20 A GFI faceplate assembly with breakers (for standless units)</p>	<b>MPL1151A</b>	 <p>Newport Camp Mate 30 A-50 A-20 A GFI faceplate assembly with breakers (for standless units)</p>	<b>RV1151A</b>
 <p>Newport Harbor Mate 30 A-50 A-20 A GFI faceplate assembly with GFCI breakers (for standless units)</p>	<b>MPL1151A-GF</b>	 <p>Newport Camp Mate 30 A-50 A-20 A GFI faceplate assembly with breakers (for standless units)</p>	<b>RV1152A</b>
 <p>Newport Harbor Mate 50 A-50 A-20 A GFI faceplate assembly with breakers (for standless units)</p>	<b>MPL1152A</b>	 <p>Newport Camp Mate 50 A-50 A-20 A GFI faceplate assembly with breakers (for standless units)</p>	<b>RV1152A</b>
 <p>Newport Harbor Mate 50 A-50 A-20 A GFI faceplate assembly with GFCI breakers (for standless units)</p>	<b>MPL1152A-GF</b>	 <p>Newport Camp Mate 50 A-50 A-20 A GFI faceplate assembly with breakers (for standless units)</p>	<b>RV1153A</b>
 <p>Newport Harbor Mate 50 A-20 A GFI faceplate assembly with breakers (for standless units)</p>	<b>MPL1153A</b>	 <p>Newport Camp Mate 50 A-20 A GFI faceplate assembly with breakers (for standless units)</p>	<b>RV1153A</b>
 <p>Newport Harbor Mate 50 A-20 A GFI faceplate assembly with GFCI breakers (for standless units)</p>	<b>MPL1153A-GF</b>	 <p>Newport Camp Mate 50 A-20 A GFI faceplate assembly with breakers (for standless units)</p>	<b>RV1154A</b>
 <p>Newport Harbor Mate 30 A-20 A GFI faceplate assembly with breakers (for standless units)</p>	<b>MPL1154A</b>	 <p>Newport Camp Mate 30 A-20 A GFI faceplate assembly with breakers (for standless units)</p>	<b>RV1154A</b>
 <p>Newport Harbor Mate 30 A-20 A GFI faceplate assembly with GFCI breakers (for standless units)</p>	<b>MPL1154A-GF</b>	 <p>Newport Camp Mate 30 A-20 A GFI faceplate assembly with breakers (for standless units)</p>	<b>RV1154A</b>

## Power (continued)















Description	Catalog number	Description	Catalog number
<p><b>Newport Harbor Mate faceplate assemblies</b></p>  <p>Newport Camp Mate 30 A-30 A-20 A GFI faceplate assembly with breakers (for standless units)</p>	<b>RV1150A-2</b>	 <p>20 A 125 V single-pole Newport Harbor Mate / Newport Camp Mate Hatteras Light Lighthouse / Powerhouse Lighthouse SS / Powerhouse SS Admiral MegaYacht</p>	<b>MPL1020</b>
 <p>Newport Camp Mate 30 A-50 A-20 A GFI faceplate assembly with breakers (for standless units)</p>	<b>RV1151A-2</b>	 <p>20 A 125 V single-pole GFCI (30 mA GFP) Hatteras Light Lighthouse / Powerhouse Lighthouse SS / Powerhouse SS Admiral MegaYacht</p>	<b>MPLGF1020</b>
 <p>Newport Camp Mate 50 A-50 A-20 A GFI faceplate assembly with breakers (for standless units)</p>	<b>RV1152A-2</b>	 <p>30 A 125 V single-pole Newport Harbor Mate / Newport Camp Mate Hatteras Light Lighthouse / Powerhouse Lighthouse SS / Powerhouse SS Admiral MegaYacht</p>	<b>MPL1030</b>
 <p>Newport Camp Mate 50 A-20 A GFI faceplate assembly with breakers (for standless units)</p>	<b>RV1153A-2</b>	 <p>30 A 125 V single-pole GFCI (30 mA GFP) Hatteras Light Lighthouse / Powerhouse Lighthouse SS / Powerhouse SS Admiral MegaYacht</p>	<b>MPLGF1030</b>
 <p>Newport Camp Mate 30 A-20 A GFI faceplate assembly with breakers (for standless units)</p>	<b>RV1154A-2</b>	 <p>50 A 125 V single-pole Newport Harbor Mate / Newport Camp Mate Hatteras Light Lighthouse / Powerhouse Lighthouse SS / Powerhouse SS Admiral MegaYacht</p>	<b>MPL1050</b>
		 <p>20 A 125/250 V two-pole Newport Harbor Mate / Newport Camp Mate Hatteras Light Lighthouse / Powerhouse Lighthouse SS / Powerhouse SS Admiral MegaYacht</p>	<b>MPL2020</b>
		 <p>20 A 125/250 V two-pole GFCI (30 mA GFP) Hatteras Light Lighthouse / Powerhouse Lighthouse SS / Powerhouse SS Admiral MegaYacht</p>	<b>MPLGF2020</b>

## Power (continued)

















Description	Catalog number	Description	Catalog number
 <p>30 A 125/250 V two-pole Newport Harbor Mate / Newport Camp Mate Hatteras Light Lighthouse / Powerhouse Lighthouse SS / Powerhouse SS Admiral MegaYacht</p>	<b>MPL2030</b>	 <p>Lighthouse/Lighthouse SS breaker filler, single-pole space</p>	<b>MPL1141BF</b>
 <p>30 A 125/250 V two-pole GFCI (30 mA GFP) Hatteras Light Lighthouse / Powerhouse Lighthouse SS / Powerhouse SS Admiral MegaYacht</p>	<b>MPLGF2030</b>	 <p>Hatteras ground fault adapter plate</p>	<b>MPL0002</b>
 <p>50 A 125/250 V two-pole Newport Harbor Mate / Newport Camp Mate Hatteras Light Lighthouse / Powerhouse Lighthouse SS / Powerhouse SS Admiral MegaYacht</p>	<b>MPL2050</b>	 <p>200 A 480 V three-pole Admiral MegaYacht</p>	<b>MPL2200</b>
 <p>50 A 125/250 V two-pole GFCI (30 mA GFP) Hatteras Light Lighthouse / Powerhouse Lighthouse SS / Powerhouse SS Admiral MegaYacht</p>	<b>MPLGF2050</b>	 <p>Transient voltage surge suppressor Lighthouse / Powerhouse Lighthouse SS / Powerhouse SS Admiral MegaYacht</p>	<b>MPLTVSS</b>
 <p>60 A 125/250 V two-pole Hatteras Light Lighthouse / Powerhouse Lighthouse SS / Powerhouse SS Admiral MegaYacht</p>	<b>MPL2060</b>		
 <p>100 A 125/250 V two-pole 100 A 125/250 V two-pole, no terminals Lighthouse / Powerhouse Lighthouse SS / Powerhouse SS Admiral MegaYacht</p>	<b>MPL2100</b>		
 <p>100 A 120/208 V three-pole 100 A 120/208 V three-pole, no terminals Lighthouse / Powerhouse Lighthouse SS / Powerhouse SS Admiral MegaYacht</p>	<b>MPL3100</b>		
<p>100 A 120/208 V three-pole, no terminals Lighthouse / Powerhouse Lighthouse SS / Powerhouse SS Admiral MegaYacht</p>	<b>MPL3100D</b>		



# Connections














Description	Catalog number	Description	Catalog number
 <p>20 A GFCI duplex Deckhand Hatteras Light Lighthouse / Powerhouse Lighthouse SS / Powerhouse SS Admiral MegaYacht</p>	<b>MPL3038</b>	 <p>100 A 480 V five-wire pin and sleeve (15-degree slant) Lighthouse / Powerhouse Lighthouse SS / Powerhouse SS Admiral MegaYacht</p>	<b>MPL5100R7W</b>
 <p>30 A 125 V locking receptacle Deckhand Hatteras Light Lighthouse / Powerhouse Lighthouse SS / Powerhouse SS Admiral MegaYacht</p>	<b>MPL3039</b>	 <p>30 A 125 V RV Newport Camp Mate Powerhouse Powerhouse SS</p>	<b>RV3042</b>
 <p>50 A 125 V locking receptacle Deckhand Hatteras Light Lighthouse / Powerhouse Lighthouse SS / Powerhouse SS Admiral MegaYacht</p>	<b>MPL3040</b>	 <p>50 A 125/250 V RV Newport Camp Mate Powerhouse Powerhouse SS</p>	<b>RV3043</b>
 <p>50 A 125/250 V locking receptacle Deckhand Hatteras Light Lighthouse / Powerhouse Lighthouse SS / Powerhouse SS Admiral MegaYacht</p>	<b>MPL3045</b>	 <p>Coax cable TV female adapter with plastic insert Newport Harbor Mate / Newport Camp Mate Hatteras Light Lighthouse / Powerhouse Lighthouse SS / Powerhouse SS Admiral MegaYacht</p>	<b>MPL1086</b>
 <p>100 A 120/240 V pin and sleeve (15-degree slant) Lighthouse / Powerhouse Lighthouse SS / Powerhouse SS Admiral MegaYacht</p>	<b>MPL4100R12W</b>	 <p>RJ45 CAT 5E high-speed internet jack Newport Harbor Mate / Newport Camp Mate Hatteras Light Lighthouse / Powerhouse Lighthouse SS / Powerhouse SS Admiral MegaYacht</p>	<b>MPL3059</b>
 <p>100 A 120/208 V pin and sleeve (15-degree slant) Lighthouse / Powerhouse Lighthouse SS / Powerhouse SS Admiral MegaYacht</p>	<b>MPL5100R9W</b>	 <p>Marine phone receptacle Newport Harbor Mate / Newport Camp Mate Hatteras Light Lighthouse / Powerhouse Lighthouse SS / Powerhouse SS Admiral MegaYacht</p>	<b>MPL3037</b>
 <p>100 A 480 V four-wire pin and sleeve (15-degree slant) Lighthouse / Powerhouse Lighthouse SS / Powerhouse SS Admiral MegaYacht</p>	<b>MPL4100R7W</b>	 <p>RJ12 CAT 3 phone jack Newport Harbor Mate / Newport Camp Mate Hatteras Light Lighthouse / Powerhouse Lighthouse SS / Powerhouse SS Admiral MegaYacht</p>	<b>RV3060</b>

## Connections (continued)

Description	Catalog number	Description	Catalog number		
	Pedestal cable assembly	<b>MPL1161</b>		Pedestal internet assembly with plate	<b>MPL1162</b>
	Lighthouse marine phone assembly with plate	<b>MPL1166</b>		Pedestal marine phone and cable assembly Hatteras Light Lighthouse SS	<b>MPL119S</b>
	Lighthouse cable assembly with plate	<b>MPL1160</b>		Pedestal phone and cable assembly	<b>MPL1174</b>
	Lighthouse complete phone and cable assembly	<b>MPL1114</b>		Pedestal phone and internet assembly	<b>MPL1176</b>
	Pedestal marine phone assembly	<b>MPL1167</b>		Pedestal phone and internet assembly with plate	<b>MPL1175</b>
	Pedestal phone assembly	<b>MPL1168</b>		Pedestal cable and internet assembly	<b>MPL1165</b>
	Pedestal cable assembly with plate	<b>MPL1171</b>		Pedestal cable and internet assembly with plate	<b>MPL1164</b>
	Pedestal internet assembly	<b>MPL1163</b>		Pedestal phone, cable, and internet assembly	<b>MPL1180</b>

















## Connections (continued)


Description	Catalog number	Description	Catalog number
	<b>MPL1179</b>		<b>MPL1181</b>
Newport marine phone assembly	<b>MPL1169</b>		<b>MPL1182</b>
	<b>MPL1170</b>		<b>RV1130</b>
Newport cable assembly	<b>MPL1172</b>		<b>RV1132</b>
	<b>MPL1173</b>		<b>RV1134</b>
Newport internet assembly	<b>MPL1115</b>		<b>RV1135</b>
	<b>MPL1177</b>		<b>RV1136</b>
Newport phone and internet assembly	<b>MPL1178</b>		
			
Newport cable and internet assembly			
			



















# Lighting

Description	Catalog number	Description	Catalog number
 <p>LED bulb only Newport Harbor Mate / Newport Camp Mate Hatteras Light Lighthouse / Powerhouse Lighthouse SS / Powerhouse SS Admiral MegaYacht Firehouse</p>	<b>MPLEDB</b>	 <p>In-line fuse (for pedestals with ceramic bulb sockets only) Mariner Hatteras Light Lighthouse / Powerhouse Lighthouse SS / Powerhouse SS Admiral MegaYacht</p>	<b>MPL3026</b>
 <p>LED kit Newport Harbor Mate / Newport Camp Mate Hatteras Light Lighthouse / Powerhouse Lighthouse SS / Powerhouse SS Admiral MegaYacht Firehouse</p>	<b>MPLEDC1</b>	 <p>In-line fuse holder (for pedestals with ceramic bulb sockets only) Mariner Hatteras Light Lighthouse / Powerhouse Lighthouse SS / Powerhouse SS Admiral MegaYacht</p>	<b>MPL3027</b>
 <p>LED kit with photocell Hatteras Light Lighthouse / Powerhouse Lighthouse SS / Powerhouse SS Admiral MegaYacht Firehouse</p>	<b>MPLEDC2</b>	 <p>In-line fuse (for pedestals with plastic bulb sockets only)</p>	<b>MPL3026P</b>
 <p>LED light kit with a top and lens (amber)</p>	<b>MPLEDC2-LH</b>	 <p>In-line fuse holder (for pedestals with plastic bulb sockets only)</p>	<b>MPL3027P</b>
 <p>LED light kit with a top and lens (blue)</p>	<b>MPLEDC2-LHB</b>		
 <p>LED light kit with a top and lens (clear)</p>	<b>MPLEDC2-LHC</b>		
<p>LED light kit with a top and lens (red, no photocell) Hatteras Light Lighthouse / Powerhouse Lighthouse SS / Powerhouse SS</p>	<b>MPLECC2-LHR</b>		
 <p>Newport LED light upgrade (LED light, photocell, wires, and new lens) Newport Harbor Mate / Newport Camp Mate</p>	<b>MPLED3P</b>	 <p>Photocell with nut and washer Newport Harbor Mate / Newport Camp Mate Hatteras Light Lighthouse / Powerhouse Lighthouse SS / Powerhouse SS Admiral MegaYacht</p>	<b>MPL3044</b>
 <p>LED brick (red) Lighthouse Lighthouse SS Hatteras Light</p>	<b>MPLED4</b>	 <p>Photocell nut and washer only Newport Harbor Mate / Newport Camp Mate Hatteras Light Lighthouse / Powerhouse Lighthouse SS / Powerhouse SS Admiral MegaYacht</p>	<b>MPL3034</b>

## Lighting (continued)











	Description	Catalog number
	Amber lens	<b>MPL6005</b>
	Clear lens	<b>MPL6008</b>
	Blue lens	<b>MPL6008B</b>
	Red lens	<b>MPL6005R</b>
	Hatteras Light Lighthouse / Powerhouse Lighthouse SS / Powerhouse SS Firehouse	
	Newport Harbor Mate amber lens (3-piece)	<b>MPL1117</b>
	Newport Harbor Mate blue lens (3-piece)	<b>MPL1117B</b>
	Newport Harbor Mate clear lens (3-piece)	<b>MPL1117C</b>
	Admiral amber lens kit (8-piece)	<b>MPL6016</b>
	Admiral clear lens kit (8-piece)	<b>MPL6018</b>
	Admiral blue lens kit (8-piece)	<b>MPL6018B</b>
	Mariner LED top assembly (amber)	<b>MPL6103-A</b>
	Mariner LED top assembly (blue)	<b>MPL6103-B</b>
	Mariner LED top assembly (clear)	<b>MPL6103-C</b>
	Firehouse red strobe light/siren	<b>MPL3020</b>

# Water















Description	Catalog number	Description	Catalog number
 <p>Lighthouse / Powerhouse water mounting plate with mounting brackets</p>	<b>MPL1132</b>	 <p>Water mounting plate U-brackets and screws</p>	<b>MPL1132UB</b>
 <p>Lighthouse complete water manifold assembly (Single 3/4-inch hose bib with 1/4-turn ball valve)</p>	<b>MPL11A</b>	 <p>Hatteras Light 1/2-inch water mounting plate</p>	<b>MPL6585</b>
 <p>Powerhouse complete water manifold assembly (Single 3/4-inch hose bib with 1/4-turn ball valve)</p>	<b>RVPH11A</b>	<p>Hatteras Light 3/4-inch water mounting plate</p>	<b>MPL6584</b>
 <p>Lighthouse complete water manifold assembly (Dual 3/4-inch hose bibs with 1/4-turn ball valves)</p>	<b>MPL11B</b>	 <p>Hatteras Light 1/2-inch brass sillcock (hose bib)</p>	<b>MPL7014</b>
 <p>Powerhouse complete water manifold assembly (Dual 3/4-inch hose bibs with 1/4-turn ball valves)</p>	<b>RVPH11B</b>	<p>3/4-inch stainless steel ball valve (hose bib)</p>	<b>MPL5271</b>
 <p>Lighthouse SS single water assembly</p>	<b>MPL11E</b>		<b>MPL5271</b>
 <p>Lighthouse SS dual water assembly</p>	<b>MPL11F</b>	<p>Watts 3/4-inch backflow preventer</p>	<b>MPL7015</b>
 <p>Lighthouse SS / Powerhouse SS water mounting plate—blank</p>	<b>MPLSS1132</b>		<b>MPL7015</b>
 <p>Lighthouse SS / Powerhouse SS water mounting plate—1 water spigot</p>	<b>MPLSS1132-1</b>	<p>Powerslide water plate assembly</p>	<b>RV1140</b>
 <p>Lighthouse SS / Powerhouse SS water mounting plate—2 water spigots</p>	<b>MPLSS1132-2</b>	<p>Water meters (new style)</p>	<b>MPL20WM</b>
			



# Housing














Description	Catalog number	Description	Catalog number
 <p>Top only Hatteras Light Lighthouse / Powerhouse Lighthouse SS / Powerhouse SS</p>	<b>MPL6003</b>	 <p>External breaker cover set—single-pole, two-pole, and three-pole Deckhand Hatteras Light Lighthouse / Powerhouse Lighthouse SS / Powerhouse SS Admiral MegaYacht</p>	<b>MPL11061</b>
 <p>Powerslide top</p>	<b>RV6010</b>	 <p>Lighthouse main door assembly kit Powerhouse main door assembly kit</p>	<b>MPL6007</b> <b>RVPH6007</b>
 <p>Marina Power and Lighting logo</p>	<b>MPLLOGO</b>	 <p>Lighthouse SS main door Powerhouse SS main door</p>	<b>MPL6007S</b> <b>RVPH6007S</b>
 <p>Marina Power and Lighting generic flip cover lid</p>	<b>MPL0001</b>	 <p>Lighthouse SS / Powerhouse SS base mounting plate</p>	<b>MPL6009</b>
 <p>20 A GFCI external cover assembly Deckhand Hatteras Light Lighthouse / Powerhouse Lighthouse SS / Powerhouse SS Admiral MegaYacht</p>	<b>MPL1101</b>	 <p>Lighthouse / Powerhouse top isolation plate</p>	<b>MPL6012</b>
 <p>30 A receptacle external cover assembly Deckhand Hatteras Light Lighthouse / Powerhouse Lighthouse SS / Powerhouse SS Admiral MegaYacht</p>	<b>MPL1102</b>	 <p>Powerslide main door assembly with amber lens</p>	<b>RV6050</b>
 <p>50 A receptacle external cover assembly Deckhand Hatteras Light Lighthouse / Powerhouse Lighthouse SS / Powerhouse SS Admiral MegaYacht</p>	<b>MPL1105</b>	 <p>Powerslide lower access panel</p>	<b>RV6052</b>

## Housing (continued)

Description	Catalog number	Description	Catalog number
	<b>RV6054</b>		<b>RV6082</b>
Powerslide receptacle faceplate	<b>RV6056</b>		<b>RV6083</b>
	<b>RV6056</b>		<b>RV6084</b>
Stainless steel spring closure and hardware Lighthouse / Powerhouse Lighthouse SS / Powerhouse SS	<b>MPL1099H</b>	Powerslide direct burial extension	<b>RV6084</b>
	<b>MPL1099H</b>		<b>MPL5500</b>
Aluminum hose and cable bracket (one)	<b>MPL1087</b>	Lighthouse SS blank stainless steel access panel	<b>MPLSS5500</b>
	<b>MPL1087</b>		<b>MPL5502-10</b>
Lighthouse / Powerhouse resin hose and cable bracket (one)	<b>MPL1087R</b>	Lighthouse base extension (height 12 inches)	<b>MPL5502-12</b>
	<b>MPL1087R</b>	Lighthouse base extension (height 14 inches)	<b>MPL5502-14</b>
Lighthouse / Powerhouse pedestal base with bus bar holder and four blank access panels	<b>MPL6004</b>	Hatteras Light base extension (10 inches)	<b>MPL5502HL-10</b>
	<b>MPL6004</b>		<b>MPL5503</b>
Powerslide post mount extension	<b>RV6080</b>	Lighthouse / Powerhouse base cap	<b>MPL5504</b>
	<b>RV6080</b>		<b>MPL5504</b>



## Housing (continued)

Description	Catalog number	Description	Catalog number		
	Newport Camp Mate main door	<b>RVPH6001</b>		Firehouse door / life ring switch	<b>MPL3050</b>
	Newport Harbor Mate main door	<b>MPL6001</b>		Firehouse door hasp	<b>MPL3950</b>
	Powerhouse direct burial mount	<b>RVPH5507</b>		Firehouse 10-lb ABC-Type fire extinguisher	<b>MPL8025</b>
	Powerhouse SS direct burial mount	<b>RVPH5507S</b>		Firehouse 20-lb ABC-Type fire extinguisher	<b>MPL8025X</b>
	Newport Harbor Mate / Newport Camp Mate mounting brackets	<b>MPL7005</b>			
	Firehouse door	<b>MPL6013</b>			
	Firehouse 24-inch life ring	<b>MPL4201</b>			
	Firehouse 30-inch life ring	<b>MPL4201-30</b>			
	Firehouse life ring bracket	<b>MPL4201B</b>			
	Firehouse blank access panel	<b>MPL6015</b>			

# Warranty policy

## Eaton Marina Power and Lighting warranty information

### I. Scope

This is an addendum to Eaton's Selling Policy 25-000, modifying the warranty article only. All other terms and conditions are in accordance with Selling Policy 25-000.

Warranty for internal components for Eaton Marina Power and Lighting products: Eaton Marina Power and Lighting internal component products are covered under the warranty set forth in Seller's Selling Policy 25-000.

### II. Warranty period

Seller warrants that the housings of all pedestals manufactured by it ("housings") will conform to Seller's applicable specifications and be free from failure due to defects in workmanship and material for a period of five (5) years from the date of first sale or delivery, whichever is earlier.

Except for the housings warranty provided herein, Seller does not provide any warranty on the pedestal or any component therein. The meters in the pedestals are manufactured by EZMeter ("EZMeter") and come with a separate five (5) year limited warranty from EZMeter against defects in workmanship and material in the meters. Seller does not warrant the meters, expressly disclaims any obligation under the EZMeter limited warranty on the meters, and does not administer claims under the EZMeter limited warranty. Any issues regarding the EZMeter meters should be addressed directly to EZMeter.

### III. Applicability of warranty

In the event a meter fails to comply with the foregoing warranty, seller will, at its option, either (a) repair or replace the defective meter, or defective part or component thereof, F.O.B. Seller's facility freight prepaid, or (b) credit Buyer for the purchase price of the Product. All warranty claims for meters shall be made in writing. Seller requires all non-conforming products be returned at Seller's expense for evaluation unless specifically stated otherwise in writing by Seller.

**Remote metering: Seller does not cover warranty for remote metering software or service.** All warranty claims for remote metering software and/or service must be directed to the respective manufacturer/provider. Seller warrants **only transmitters/transponder hardware and the install** in its pedestals according to the warranty set forth in Seller's Selling Policy 25-000.

This warranty **does not** cover failure or damage due to storage, installation, operation, or maintenance not in conformance with Seller's recommendations and industry-standard practice or **due to accident, misuse, overvoltage, submersion, abuse or negligence.** This warranty does not cover reimbursement for labor, gaining access, removal, installation, temporary power or any other expenses, which may be incurred in connection with repair or replacement. This warranty is void if factory seal is broken.

**This warranty does not cover wire harnesses, current transformers (CTs) and counters. These components are covered under Selling Policy 25-000.**

This warranty does not apply to equipment not manufactured by Seller. Seller limits itself to extending the same warranty it receives from the supplier.

### IV. Limitation of warranty, remedies and liability

In the event the housing fails to comply with the foregoing warranty, Seller will, at its option, either (a) repair or replace the defective Housing, or defective part or component thereof, F.O.B. Seller's facility freight prepaid, or (b) credit Buyer for the purchase price of the Product. All warranty claims for Housings shall be made in writing. Seller requires all non-conforming products be returned at Seller's expense for evaluation unless specifically stated otherwise in writing by Seller.

This warranty does not cover failure or damage due to shipping, storage, installation, operation or maintenance **not** in conformance with Seller's recommendations and industry-standard practice or **due to accident, misuse, overvoltage, submersion, abuse or negligence.** This warranty does not cover reimbursement for labor, gaining access, removal, installation, temporary power or any other expenses, which may be incurred in connection with repair or replacement. Paint touch-up maintenance may be required over the life of the product and is the sole responsibility of the Buyer.

This warranty does not apply to equipment not manufactured by Seller. Seller limits itself to extending the same warranty it receives from its suppliers.

# Maintenance and cleaning

## Operation and maintenance for Marina Power and Lighting units

Eaton's Marina Power and Lighting units are designed to withstand the harsh marine exterior environment. Very little maintenance is required to keep the units looking new for many years and to keep the warranty effective.

### I. Exterior maintenance

1. To remove dirt, grime, and bird droppings, use a mild solution of dishwashing detergent at approximately one teaspoon per gallon of warm water.
2. DO NOT use any solvent or corrosion-inhibiting products on any part of the unit. This can cause serious stress cracking of the engineered resins.

### II. Interior maintenance

1. Before attempting the following maintenance procedures, turn off the power to the unit at the power supply panel (note the breakers on the unit DO NOT turn the unit power supply off and the bus bars will be energized).
  - a. Exposing the bus bar assembly:
    - Lighthouse and Powerhouse: Annually, the four screws holding the top of the unit to the base should be removed and the unit should be tilted over to expose the bus bar area.
    - Lighthouse SS: Annually, remove the access panel (14 screws) to expose the bus bars.
    - Hatteras: Annually, remove the light assembly (4 screws at base of light) and the plastic barrier to expose the bus bars.
    - Newport Harbor Mate and Camp Mate: Annually, remove the light assembly at the bottom of the unit to expose the bus bars.
  - b. Maintenance of bus bar assembly:
    - On all units, the bus bars should be visually examined for excessive heating. If potentially faulty or loose joints are found, they should be tightened or replaced.
  - c. If mechanical lugs are used instead of the stud-lug bus assembly:
    - In the cases where mechanical lugs instead of the stud-lug bus assembly are used, it is very important that they be examined closely. Most mechanical lugs are made of aluminum and are very susceptible to galvanic corrosion. If the set screw cannot be tightened, replace the lug. If there appears to be corrosion around the copper to aluminum connection, remove the copper wire and clean the wire, coat the wire with an anti-corrosion grease, and retighten the assembly.
2. The receptacles and breakers should be examined annually, and if any sign of heating is evident, the receptacles or breakers should be replaced.
3. DO NOT spray any solvents on the electrical components. Solvents will cause stress cracking of the polymeric materials.

### III. Lighting assembly

1. To test the lighting assembly, the photocell should be covered with a piece of black tape and in about 2–3 minutes the light should illuminate. If this does not occur, the following items should be checked: photocell, bulb, and ballast.

### IV. Winterizing

1. The water system should be purged with air and each ball valve should be opened and closed after the system has been drained. This will remove the slug of water that remains in the ball.

### V. Operation

1. Insert the proper end of the shore power cord into the boat's power inlet connection, twist the plug to lock, and then tighten the locking plug retainer by twisting the large nut until the unit is tight to the boat.
2. With the breakers off, insert the shore power cord into the receptacle and twist the plug clockwise until the plug locks into the receptacle.
3. With both connections secured, turn on the breaker. The power indicator on the boat should indicate a successful attachment of the plug and the receptacle.



**Eaton**  
1000 Eaton Boulevard  
Cleveland, OH 44122  
United States  
Eaton.com

© 2022 Eaton  
All Rights Reserved  
Printed in USA  
Publication No. BR620019EN / Z25879  
January 2022

Eaton is a registered trademark.

All other trademarks are property  
of their respective owners.

Follow us on social media to get the  
latest product and support information.

